

## CONTINUOUS WORK STATION MONITOR

(Model: WSM-02)

The Model WSM-02 is designed for continuously monitor the connections of two ESD wrist strap & work surface.



**WRIST STRAP:** two-wrist strap sections continuously monitor the wrist strap to detect loss of continuity between operators and monitor. Conditions such as broken coils cords and improper contact with the skin are detected instantly to alert the operator before serious and expensive ESD damage can occur. As there is no resistance return path from the wrist strap, it uses the “capacitive AC pulse principle” to check if the operators are adequately connected to the instrument. The wrist strap sections are automatically activated when wrist straps are plugged in. continuous monitoring reduces the need for periodic checks and also ensures greater security.

**ESD WORK SURFACE:** The work surface is monitored by a DC Resistive principle and a warning is given in case the surface to ground resistance exceeds the safe threshold value of 10 Meg ohms.

**FEATURES:** ABS Plastic box with external mounting brackets to mount the monitor under the table for saving work surface space

### **SPECIFICATIONS:**

- |                   |  |
|-------------------|--|
| 1. Pass Threshold | : under 4 Meg ohms for wrist straps<br>: Under 10 Meg ohms for MAT   |
| 2. Indications    | : Green LED for wrist strap PASS<br>: Flashing Red LED for wrist strap FAIL<br>: Steady Red LED for mat FAIL |
| 3. Audible alarm  | : For Fail modes.  |
| 4. Input power    | : 12V @ 500 ma DC  |
| 5. Accuracy       | : +/-10%   |
| 5. Repeatability  | : +/-10%   |
| 6. Dimensions     | : 125 x 65 x 35mm  |
| 7. Weight         | : 130 Gms  |
| 8. Warranty       | : One year   |
| 9. Optional       | : Grounding Cords & 12V Adopter  |